AWRON BMW EVC SMART CONTROL




Supported BMW models


- **M135i** F20/ F21
- **M135iX** F40
- **140i** F20/ F21
- **M135i** F70 NEW
- **240i** F22/ F23
- **M235i** F22/ F23
- **M235iX** F44
- **M235 xD** F74 NEW
- **M235L xD** F78 NEW
- **M240iX** G42 NEW
- **M2** F87
- **M2 Comp.** F87
- **M2** G87
- **M3** F80
- **M3** G80
- **M3 Comp.** G80
- **340i** F30/ F31
- **340i** G20
- **M4** F82
- **M4** G82
- **M4 Comp.** G82
- **440i** F32/ F33/ F36
- **M440i** G22/ G23
- **M5** F10
- **M5** F90
- **M5** F90
- **M5** G90/G99 NEW
- **550i** F10/ F11
- **550i** G30
- **M6** F06/ F12/ F13
- **650i** F06/ F12/ F13
- **M8** F91/ F92
- **X2 M35iX** F39
- **X3 M40iX** G01
- **X3M** F97
- **X4 M40iX** G02
- **XM** G09 NEW
- **X4M** F98
- **X5M** F85
- **X5M** F95
- **X5** F15
- **X5** G05
- **X6M** F86
- **X6M** F96
- **X6** F16
- **X6** G06
- **X7** G07
- **Z4 M40i** G029

System

433MHz Remote Control







Function

433MHz Remote Control Version 1



Remote Control Functions

Open flap:
Pressing the “Open flap” button opens the exhaust flap and keeps it open, regardless of the current driving mode.

Close flap:
Pressing the “Close flap” button closes the exhaust flap and keeps it closed, regardless of the current driving mode.

Flap open (Memory + Open flap):
When the Memory button and the “Open flap” button are pressed simultaneously, the exhaust flap will remain permanently open at the next engine start.

Stock mode (Memory + Stock flap):
Pressing the Memory button and the “Stock flap” button simultaneously activates stock mode.
In this mode, exhaust flap control is handled by the engine control unit. The signal is passed through 1:1.

Flap closed (Memory + Close flap):
When the Memory button and the “Close flap” button are pressed simultaneously, the exhaust flaps will remain closed at the next engine start.

Contact

Inh. Robert Sop
Lerchenstrasse 10
80995 München
Germany

Tel. +49 (0)89 37911860
E-Mail: info@awron.de
Webseite: www.awron.de